

This maintenance and cleaning guide is intended for all SPORTMAT products made from SBR/EPDM rubber. These recommendations are given only as guidance to our customers. PVP Triptis GmbH cannot accept responsibility for loss or damage that may result from the use of this information due to variations in working conditions and/or workmanship of the installer. Users are advised to perform their own tests for a particular application and assign installers that are familiar with this type of rubber flooring product.

Cleaning and Maintenance Procedures:

1. Initial Cleaning

- a. Remove all surface debris or sand by sweeping with a soft nylon brush or vacuuming with a high powered vacuum cleaner.
- b. Scrub floor using a neutral non aggressive cleaning agent and a microfiber scrubber or pad. Do not flood the floor with water or leaning agent.
- c. Pick up the moisture with a wet vacuum, rinse the floor with clean water, picking up the water again with a wet vacuum.
- d. Allow the floor to dry thoroughly for 6-8 hours

2. Daily/regular Cleaning

- a. Sweep, dust mop or vacuum the floor to remove surface soil, debris, sand and grit.
- b. Damp mop with a microfiber mop or auto-scrub using a neutral non aggressive cleaning agent.(TIPP: no alkaline cleaning agent)
- c. Afterwards wipe the floor with clean water and pick up solution with a wet vacuum.

3. Maintenance

- a. Sweep and dry vacuum floors at regular intervals.
- b. Heavy siled surfaces should be wiped with water an a non-aggressive cleaning agent. Wet areas should be dried with a wet/dry vacuum.
- c. Always allow the floor to dry thoroughly
- d. Avoid flooding the floor with water

Warranty does not cover dissatisfaction due to improper installation, normal wear and tear, damage from improper usage or general misuse including and without limitation: burns, cuts, tears, scratches, scuffs, damage from high heels or spiked shoes, damage from rolling loads, damage from cleaning products, slight shade variations or shade variations due to exposure to direct sunlight, or differences between samples/photographs and actual flooring.

Inspect all rolls for visial defects including shade variances before installation begin. No labor claim will be honoured on material installed with visual defects or shade variances. Ensure that all job sites and subfloor requirements are met.